

Ignition Edge Panel

Standalone HMI

Embed Ignition Edge Panel onto a device, such as a touch panel, to provide a stand-alone HMI with local access to an edge-of-network device, with unlimited tags.

